

# TOOLS & MISCELLANEOUS ITEMS NEEDED FOR CONSTRUCTION

#8 x 1 1/2" SCREWS OR #9 x 1 5/8" LIFE-COAT SCREWS

#9 x 3" SCREWS

MINIMAL EXPANDING FOAM & FOAM GUN

PREMIER MASTIC / PANEL SEALANT

CAULKING GUN (QUART SIZE)

ELECTRIC FOAM CUTTER

2" NYLON LOAD STRAP (WITH FLAT HOOK)

LIFTING PLATES FOR ROOF & TALL WALL PANELS

PRE-CUT TREATED BOTTOM PLATE FOR WIDTH

3/8" DRILL (CORDLESS)

1/2" DRILL

CIRCULAR SAW

RECIPROCATING SAW

1 1/4" OR 1 1/2" CHIPPER BIT (FOR ELECTRICAL CHASE THROUGH PLATES)

R2 & R3 SQUARE DRIVE BIT, & #30 TORX BIT

4'-0" LEVEL

CHALK LINE

SLEDGE HAMMER

HARD WOOD BLOCK (APPROXIMATELY 8" x 12")

DRILL BIT FOR ANCHOR HOLES IN BOTTOM PLATE

HAMMER

JIMMY'S STRAP JACK PANEL PULLER (OPTIONAL)

NOTE: ANY BUILDING SIDEWALL THAT HAS 60'-0" OR MORE WITH NO PARTITIONS MUST HAVE PROPER BRACING FROM RAFTER TO SIDEWALL FOR STRUCTURAL STRENGTH.

EXAMPLE: KNEE BRACING, PARTITION WALL, OR TEMPORARY BRACING UNTIL SUCH BRACING IS COMPLETED.